

F100 Manual

V1.0

A. Specifications

Transmitter		Receiver	
Size	235*158*36mm	Size	103*49*10mm
Material	ABS	Material	ABS
Power	100mW	Frequency	315MHz
Frequency	315MHz	Sensitivity	-106dB
Range	1000m(open area)	Battery	3.7V200mha
Power	DC/9V1A	Standby time	≥20hours
Max pager Qty	98	Standby power	25mW
Code	learning code	Range	1000m (open area)
Keys life	1M	Mode	beep/flash/vibrate
Waterproof	Not	Waterproof	proof for splashing water

B. Operating method

1、 Number Program

Attention:It has been done in the factory.

When the base and the pagers is charging and turned on, take off the advertising paper on the pager, and long press the yellow metal button. When the two lights on the right side are on, enter your number on the keyboard and press the "CALL " button within 5 seconds ,the pager number will change and done.

2、 Power on/off

On — connect to the power supply, the pagers will auto power on.

Off— Put the pagers on charging base when charging, then enter “99” on the keyboard, and press “call” button,the pager will auto power off.

Attention: Please turn off the pager during closing time to avoid affecting battery life.

3、 Set the beep/vibrate/Flash time

With the pager turned on, take off the advertising paper, then press the yellow metal button. One reminder light on, represents the beep/vibrate/flash time of 8 seconds. The time is increased 8 seconds every time you press the button shortly. And the maximum ,5 lights on, the time can be increased to 40 seconds.

4、 Turn off the beep

With the pager turned on, take off the advertising paper.Then shortly press the yellow metal button a few times untill the lights are all off.