



The inflatable winter pool cover is made from a durable PVC tarpaulin which is chlorine, frost and UV resistant.

Thanks to the bulbous shape, the contaminants no longer end up in your pool.


Unlike other winter covers that simply lie flat on the swimming pool, inflatable winter pool cover does not get rainwater or melt water in your pool, but simply rolls off the pool cover. This means that there is no risk that the winter cover will slide into the pool.

The special thing is that it is filled with air and turns into a floating cover that prevents flowers, leaves, rainwater and snow from getting into your pool. It goes without saying that it also serves as solar thermal insulation (air is the best insulation there is).

How to use the valve



Inflatable valve




Press to release air




Inflate with an air pump


How to install Anchor?



Drill hole in the ground
: 19mm Depth:40mm



Insert anchors to the
hole by a hammer



Adjust with hex key



Finished