


Tools May Required (Not Included)



(6mm drill)
(depth >30mm)

Electric drill




Step ladder




Screwdriver


Accessories



controller



Hanging Line



Needed Screws

BEFORE INSTALLATION

Please read this instruction before install neon sign.

CONNECTION AND POWERING STEP

1. Connect neon lights and LED controller.
2. Connect LED controller and 12V adapter.
3. Insert the plug into the power supply.
4. Turn on the switch

CAUTION

1. The remote control can operate all modes, point the remote control at the LED Controller within 5 meters.
2. Do not connect to the power during installation.
3. The working voltage of this product is AC/DC 12V, please use power adapter with appropriate output voltage, or the product will be damaged.
4. Do not peel off the neon tubes from their backboard.
5. Do not disassemble the product.
6. The product is not waterproof, keep away from water, prevent this product from getting wet. Indoor use only.
7. Keep away from fire and heat sources, or it will be damaged.
8. It will delay about 2-3 seconds before working due to AC/DC transformation when the product starts up.
9. The pilot lamp will stay on as long as the power adapter is working. Please check the AC plug and its connection if the lamp is off and blinks. If this problem persists, the adapter may have been damaged and should be replaced by new one.
10. If the product does not work after power on, please check the power adapter and its wires to make sure that they are connected reliably. If the problem persists, do not try to repair it yourself, please contact us for customer service.