






GROW TENT ASSEMBLY INSTRUCTIONS

1. FOR TENT SIZE: 240X120X200-230CM

300X150X200-230CM


2. COMPONENTS

C		6 pcs
B		6 pcs
A		13 pcs
E		2 pcs
F		4 pcs


(1) TENT (2) FLOOR TRAY

(3) FILTER STRAPS (4-7) CORNER ADAPTER


(A-F) FRAMEWORK SUPPORT



STEP 1




STEP 2



UNZIP ALL ZIPPERS OF THE TENT TO COVER ALL THE WAY. FIRST GENTLY PULL UP THE TOP OF TENT SHELL ON THE FRAME TO MAKE SURE ALL CORNERS ARE SQUARELY IN PLACE. HAVING A HELPER MAKES THIS PROCESS EASIER.

STEP 3



THEN PULL THE BOTTOM OF TENT SHELL TO COVER THE BASE OF TENT FRAME PROPERLY. PUT ALL HANGING BARS ON THE TOP OF FRAME.

STEP 4

